







# ferroamp

## CURRENT SENSORS

		Range	Diameter Size Cable length	Accuracy / Phase Angle	CT Ratio	For use with
	<b>CT 100A PA00294</b>	2 .. 100A	13 mm 22 x 32 x 58 mm 10m	+ - 2% 7°	2000	Energyhub Energyhub XL
	<b>CT 160A PA00295</b>	8 .. 160A	16 mm 32 x 31 x 45 mm 10m	+ - 2% 5°	4000	Energyhub Energyhub XL
	<b>CT 300A PA00296</b>	15 .. 300A	36 mm 42 x 66 x 92 mm 10m	+ - 1.5 % 6°	6000	Energyhub Energyhub XL
	<b>Rog 600A PA00965</b>	60 .. 600A	120 mm NA 1m	+ - 3 % 8°	12000	Energyhub XL (230/24V supply included)
	<b>Rog 1200A PA00966</b>	120 .. 1200A	120 mm NA 1m	+ - 3% 8°	24000	Energyhub XL (230/24V supply included)
	<b>Rog 2000A PA00967</b>	200 .. 2000A	120 mm NA 1m	+ - 3% 8°	40000	Energyhub XL (230/24V supply included)